




newsuperantenna.com
Super Antenna Systems for HF - VHF - UHF

TM1 SuperMount™ Low Profile Tripod for Portable Antennas



Instructions for Use

- Choose a flat level surface such as a table, bench, deck, or floor to set up the TM1 Tripod.
- Unpack all the contents of the tripod and antenna package and lay it out on the surface.
- Locate the Tripod Hub **H** and 3 Tripod Legs **L**.
- Screw all 3 Tripod Legs **L** into the angled Tripod Leg Sockets **S** of the Tripod Hub **H**.
- Set the Tripod **T** on the level surface.
- Connect one end of your coaxial cable to the Coaxial Connector **C** and the other end to the antenna connector of your scanner radio. (You may need a coax cable and coaxial connector adapter)
- Locate your Antenna **A**.
- Screw your Antenna **A** into the Antenna Fitting **F** on top of the Tripod **T**.
- Gently extend extend your Antenna **A** to full length.
- The TM1 tripod and your antenna is now completely set up and ready to use.
- Connect your RG58 or RG8x coax cable and radio (*available separately*) to the Coaxial Connector.
- Attach radial sets (*available separately*) to the mount connector terminals. Wires may droop down.

Contents:

(1) Tripod Hub (3) Tripod Legs